



A185A

Plasma Rocket Lamp



Instruction Manual

Thank you for buying this Cheetah Leisure Plasma Rocket Lamp. We hope it brings you much enjoyment.

Please carefully read the following instructions and warnings and retain this manual for future reference.

Firstly, carefully inspect the product and its power supply for signs of damage. If any are detected, please do not use and refer back to your supplier.

CAUTIONS AND WARNINGS

- This item is not a toy. Children must not play with the item.
- Children over 12 may use this product but only with adult supervision.
- Periodically check this product for damage. If any is detected, then stop using the product and disconnect it from the mains.
- Do not use this product in damp or wet locations.
- Do not use this product where there are flammable liquids or gasses such as petrol etc.
- For indoor use only.
- Do not leave this product switched on while not attended.
- Disconnect the unit when not in use.
- Only use this product on a firm, flat, stable surface.
- Do not allow the lead for the power supply to get trapped or become a trip hazard.
- Not for use with power outputs from computers or similar devices.
- Only use with the power supply provided.
- Do not allow metal objects to touch the glass vessel



- Do not attempt to remove the glass vessel from its base. **Risk of Electric shock**

INSTALLATION AND USE

- Connect the DC end of the Power Supply lead to the base of the unit.
- Plug the power supply into the mains and switch on.
- Move the switch on the base of the unit to the right to switch on.

INFORMATION

It is safe to touch the glass and by doing so you will change the effect of the product. In normal operation the glass will warm up and a slight tingling sensation will be felt in the fingertips. For optimum effect use the product in a slightly darkened room.

TECHNICAL SPECIFICATION

Product

Material.....Plastic and Glass
Power 12V~
Product Weight.....750g
Product Dimensions95 x 95 358mm

Power Supply

Power Input 230V~, 50Hz
Output12V~, 500mA, max 6VA

DISPOSAL AND RECYCLING

You must not dispose of this product with domestic household waste.
Most local authorities have specific collection system for electronic items and disposal is free of charge to the end-user.

MAINTENANCE

- Store in a dry clean space when not in use.
- Disconnect from the mains supply in when not in use
- Clean only with a slight damp cloth

Electrovision Ltd., Lancots Lane, Sutton, St. Helens, Merseyside WA9 3EX
website: www.electrovision.co.uk

