



A186L Lava Lamp

Instruction Manual



Thank you for buying this Cheetah Leisure Colour Lava Lamp. We hope it brings you much enjoyment.

Please carefully read the following instructions and warnings and retain this manual for future reference.

Firstly, carefully inspect the product for signs of damage. If any are detected, please do not use and refer back to your supplier. This product is designed for temporary use of between 1-3 hours.

CAUTIONS AND WARNINGS

- This item is not a toy. Children must not play with the item.
- Children over 12 may use this product but only with adult supervision.
- Periodically check this product for damage. If any is detected, then stop using the product and disconnect it from the mains.
- Do not use this product where there are flammable liquids or gasses such as petrol etc.
- For indoor use only.
- Only use this product on a firm, flat, stable surface.
- Do not allow the glass to become broken or damaged
- Do not use in damp or wet locations.
- Very hot surface. Do not touch when in operation.
- Do not shake the product when in operation.
- Do not move the product when in operation. Allow 2-3 hours to cool down before moving.
- This product is a lighting effect and is not designed to be used for room illumination.
- Do not drink the fluid inside this product.
- Do not use where animals or children might cause disruption or damage to the product.
- This product is not designed for constant illumination.
- Do not allow the power supply lead to get trapped or caught up and become a trip hazard.

INSTALLATION AND USE

- Place the unit on a firm, flat stable surface away from children and pets and other causes of damage or disturbance.
- Add the metal cap.
- Connect the DC power supply lead to the base of the product.
- Connect the power supply to the mains and switch on.
- Allow the product 1 hour to warm up
- Switch off after a maximum of 3 hours.

INFORMATION

For optimum effect use the product in a slightly darkened room

CHANGING THE LAMP

- Disconnect the product from the power supply and allow the product to cool until the wax has hardened. Do not touch the product or attempt to change the lamp while hot.
- Remove the screw on the stem of the product and withdraw the glass pod. Careful place this down in such a way it does not get damaged.
- Remove the old lamp from its lamp base.
- Carefully replace the lamp with a G4 12V 20W Bulb. Hold the envelope of the lamp with tissue paper to stop grease and dirt getting on to the lamp.
- Carefully replace the glass pod back into the base lining up the socket with the case hole. Insert the retaining screw making sure it is in place and is securely holding the glass pod.
- Put the unit back in to position and leave to settle before turning on.

CHANGING THE LAMP

Input: 230Vac @50Hz

Output: 12V 250ma

Lamp: G4 12V 20W (max)

Lamp: Oil based wax and Water

DISPOSAL AND RECYCLING

You must not dispose of this product with domestic household waste.

Most local authorities have specific collection system for electronic items and disposal is free of charge to the end-user.

MAINTENANCE

- Store in a dry clean space when not in use.
- Disconnect from the mains supply when not in use
- Allow the product to cool down and clean only with a slightly damp cloth

Electrovision Ltd., Lancots Lane, Sutton, St. Helens, Merseyside WA9 3EX
website: www.electrovision.co.uk

