

# ELIMINATOR STRYKER MAX - DMX TRAITS

CHANNEL		DMX VALUES	FUNCTION
20Ch	26Ch		
1	1	000 - 255	<b>Pan</b> , 8-bit, 0° - 540°
	2	000 - 255	<b>Pan Fine</b> , 16-bit
2	3	000 - 255	<b>Tilt</b> , 8-bit, 0° - 190°
	4	000 - 255	<b>Tilt Fine</b> , 16-bit
3	5	000 - 255	<b>Red</b>
4	6	000 - 255	<b>Green</b>
5	7	000 - 255	<b>Blue</b>
6	8	000 - 255	<b>White</b>
	9	000 - 255	<b>Hue</b>
	10	000 - 255	<b>Saturation</b>
			<b>CCT Presets</b>
	11	000	No Function
		001 - 027	2800K
		028 - 055	3200K
		056 - 083	3600K
		084 - 111	4500K
		112 - 139	5000K
		140 - 167	5600K
		168 - 195	6200K
		196 - 223	6800K
		224 - 251	7500K
		252 - 255	8500K
			<b>Color Macros</b>
7	12	000	Off
		001 - 255	Color Macros, Macro 1 - Macro 255
			<b>Effect</b>
8	13	000	Effect Off
		001 - 100	Wave
		101 - 200	Dream
		201 - 255	Color Chase
9	14	000 - 255	<b>Glory Red</b>
10	15	000 - 255	<b>Glory Green</b>
11	16	000 - 255	<b>Glory Blue</b>
12	17	000 - 255	<b>Glory Dimmer</b>
			<b>Glory Effect</b>
13	18	000 - 015	Glory Effect close
		016 - 035	Glory single LED effect
		036 - 055	Glory 3pcs LED effect
		056 - 075	Glory 6pcs LED effect
		076 - 095	Glory 12pcs LED effect
		096 - 115	Glory 3pcs LED-4 modules effect

# ELIMINATOR STRYKER MAX - DMX TRAITS

CHANNEL		DMX VALUES	FUNCTION
20Ch	26Ch		
13	18		<b>Glory Effect (continued)</b>
		116 - 135	Glory 6pcs LED-4 modules effect
		136 - 155	Glory 4 modules effect
		156 - 175	Glory loop fill effect
		176 - 195	RGB 3 colors rainbow effect
		196 - 215	RGB 3 colors effect
		216 - 235	Glory rainbow effect
		236 - 255	Glory segment effect
14	19	000 - 255	<b>Glory Speed</b>
15	20	000 - 255	<b>Zoom</b> , minimum to maximum
16	21		<b>Inner Rotate</b>
		000 - 127	Positions
		128 - 190	Clockwise, fast to slow
		191 - 192	Stop
		193 - 255	Counter-clockwise, slow to fast
17	22		<b>Shutter</b>
		000 - 003	Off
		004 - 127	Strobe, slow to fast
		128 - 191	Pulse Strobe, slow to fast
		192 - 251	Random Strobe, slow to fast
	252 - 255	Open	
18	23	000 - 255	<b>Dimmer</b> , 0-100%
	24	000 - 255	<b>Dimmer Fine</b> , 16-bit
19	25	000 - 255	<b>Pan/Tilt Speed</b> , fast to slow
20	26		<b>Reset</b>
		000 - 021	Off
		022 - 025	No Function
		026 - 076	Reset Effect (hold 3 sec)
		077 - 128	Reset Pan/Tilt Motor (hold 3 sec)
		129 - 255	Reset All (hold 3 sec)

**COLOR MIXING NOTE:** This unit features four different modes of color mixing, and they are configured in a hierarchy so that higher priority modes will override lower priority modes. The priority levels are listed below, from highest to lowest priority:

1. Hue / Saturation
2. Color Macro
3. CCT Preset
4. RGBW