



# Professional Installation Half Mirror Ball with Rotator

#### **IMPORTANT**

### Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

#### **BEFORE USE**

You **must** inspect this product and its power lead before use for any signs of damage. If the products or its lead are damaged in anyway, **DO NOT** use it, and contact your supplier immediately.

#### PRODUCT SAFETY

- Professional install product only. This product must only be installed by a
  qualified professional person and only after conducting a site survey and risk
  assessment for its suitability to be used in that location. The installation must
  conform to all local wiring and safety legislation.
- This product must be wired through a switched fused spur.
- For indoor use only.
- Do not use in bathrooms, or in wet or damp locations.
- Only attached to strong stable surfaces that can withstand the weight of the product.
- Do not leave this product switched on when not attended.
- The product should be switched off and disconnected from the mains when not in use.
- The product and its electrical parts should be inspected for damage, wear and the ingress of dust and dirt by a professional person regularly. If any are found stop using immediate and repair or replace.
- Only use this product for its intended use.
- Children must not play with this product
- Do not attach or allow items to be deposited in this product.
- Do not swing from or attempt to hold the unit.
- This product should be mounted at a heigh of at least 2m to the apex of the unit.
- Do not use in the vicinity of petrol or other flammable gasses.
- Do not use in the vicinity of heat sources such as fires or cookers.
- Always wear gloves when handling this product. Cut risk

#### Installation



After conducting a site survey and risk assessment to ensure the suitability of the location you wish to fit the product attach the unit to the surface via the 4 fixing holes that can be found on the bracket on the underside of the product. Fixings are not supplied and must be provided by the installer after ensuring they are suitable for the surface material the unit is going to be fitted to.

Always check the unit is stable and fixed in place and working correctly

before use. The unit should run smoothy and be free of vibration.

Make sure the power cable is secure and cannot get tangled up in the equipment. If the unit is to be fitted to a ceiling it must be a minimum of 2m from the floor to the apex of the unit.

## **MAINTENANCE**

Always disconnect the unit from its power supply before cleaning.

### Cleaning and inspection.

- This unit must be inspected regularly for damage, wear and the ingress of dust and dirt into the unit by a professional person. If any is found stop using the unit until the issue has been resolved.
- The glass facets can be cleaned with a soft damp cloth, with a drop of washing-up liquid. Dust can be removed by using a small paint brush or similar.
- 3) Always wear gloves when handling the product.

# **DISPOSAL AND RECYCLING**

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

# **TECHNICAL SPECIFICATION**

Code	Size	RPM	Dims	Weight Kg	Power	Voltage	Colour
G007PA	8"	2.5	200x200x100	1	3.5W	230V	Silver
G007PB	12"	2.5	300x200x150	1.5	3.5W	230V	Silver
G007PC	16"	1	400x400x200	3.7	3.5W	230V	Silver
G007PD	20"	1	500x500x250	5.3	3.5W	230V	Silver

### SERVICE WARRANTY

Electrovision guarantees the product free from defects in materials and workmanship for a period of one year.

Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on (0845) 459 4816. The help desk is open from 8 am until 1 pm.

Electrovision Ltd., Lancots Lane, Sutton Oak, St. Helens, Merseyside. WA9 3EX

website: www.electrovision.co.uk